

## Tire Spreader Spare Parts List

519-917-4 Tire Spreader USA  
 519-915-0 Tire Spreader normal  
 519-915-8 Tire spreader Super

Pos.	Part. No.	Description
1	GR 3000	base (Chassis)
2	GR 3001	upper guide
3	GR 3002	lower guide
4	GR 3003	control panel
5	GR 1154	lifting (spreading)cylinder
6	GR 1071	cylinder adapter
7	GR 3006	cylinder cantilever
8	GR 3007	cylinder bolt
9	GR 3008	locking ring
10	GR 3009	lever bolt, long
11	GR 3010	lever bolt, short
12	GR 1101	air hose fitting 1/4" x 6/4
12a	GR 1102 A	air hose fitting 1/8" x 6/4
12 b	GR 1103 A	silencer 1/8"
12 c	GR 3067	air hose fitting 1/8" 6/4
13	GR 3014	air fitting 1/4"
14a	GR 3015 A	T-type fitting revolving 1/4"
16a	GR 3065	valve
17	GR 3018	spreader frame
18	GR 3019	rollers
19	GR-3020	roller axle
20	GR 3021	joint bolt
21	GR 3022	locking ring
22	GR 3023	cross-piece lever
23	GR 3024	traction rod
24	GR 3025	cardan block
25	GR 1063	lock nut M 14 DIN 985
26	GR 3027	cross piece section
27	GR 3028	right claw extension
28	GR 3029	left claw extension
29	GR 3030	right spreading claw
30	GR 3031	left spreading claw
31	GR 3032	hexagon cap screw M12 x 110 DIN 933
31a	GR 3033	lock nut M 12 DIN 985
32	GR 3034	cotter pin
33	GR 3035	hexagon cap screw M12 x 70 DIN 933
34	GR 3036	spreader foot pedal
35	GR 1188	hexagonal nut
36	GR 3038 A	ball and screw M 10 x 55 DIN 912
38	GR 3040	spring
40	GR 1112	pneumatic air hose 0 6/4 5 mtr

41	GR 1130 A	set of gaskets for pneumatic cylinder Magra
42	GR 3042	holder for filter unit
43	GR 3043	air fitting, female, US type
44	GR 3044	air fitting, male, US type
45	GR 3045	pneumatic hose fitting 1/4 " 4/6
46	GR 3046	pneumatic hose fitting 1/4 "
47	GR 3047	pneumatic hose fitting 1/4 " 4/6
48	GR 3048	air distributor
49	GR 3049	1/4 " adapter piece
50	GR 9855	filter/oiler unit, compl. Typ small
50 a	GR 3050 A	pressure gauge 1/8 "
50 b	GR 1081 A	glass for filter unit typ small
50 c	GR 1080 A	glass for oiler typ small
51	GR 3051	electric cord with plug
51 a	GR 3052	electric cord for transformer
51 b	GR 3053	electric cord for light
52	GR 3054	electric cord protector PG 13,5
53	GR 3055	electric switch
54	GR 3056	transformer
55	GR 3057	cord holder
56	GR 3058	light holder guide
57	GR 9849	holding spring with screw
58	GR 3060	light unit bracket
59	GR 3061	bulb
60	GR 3062	light unit ( without bulb)
	GR 3064	ramp w. attachments
	GR-3065a	handle for valve
	GR 9861	toolshef
	519-916-7	EM-Extention
	GR 9854	light unit cpl.